



# **Assembly Instructions**

## **Lawn Edge Tapes**

Attention: store in a dry place until use and handle them wearing gloves at all times. Cut the tapes with caution as the resulting sharp edges may cause injuries. A second person is beneficial during installation.

Unroll the tape in your garden. The tape will gradually relax until flat. Use a spade to prepare the soil for the tape installation. Rock the spade back and forth in the soil to create V-shaped indentations. To ensure straight lines, use a plank of wood to guide you. If you prefer wavy edges, use a garden hose to map out the perfect curves.

Cut the lawn edge tape to size with tin snips and install in the prepared grooves. Please refrain from using hack- or jigsaws as they frazzle the edges, nor use grinders as they damage the surface and impact the longevity of the product.

Protect the top edge with a piece of wood and carefully tap the tape to the desired final height - we recommend to leave approx. 2 - 3 cm.