



Assembly Instructions

Lawn Edging narrow



Wear gloves at all times!

Combine the edging at an angle of approx. 90 degrees until the click-fix elements engage in the slot. Whether the top fold is facing inwards or outwards is up to you. Prick the soil with a spade to install the edging. For a V-shaped indentation, rock the spade back and forth in the soil. To achieve straight lines, use a wooden board or similar as a guide. To achieve a perfect curve, use a garden hose to guide the way.

Tip: carefully bend the edging around a barrel or bin for a consistent curve.

Connect two to three elements into a unit and place them into the groove at an angle, with one end poking out completely. Join the next element here at a 90-degree angle, unfold and continue place into the groove. Protect the top with a piece of wood and carefully tap the edging to the desired height - we recommend approx. 2 - 3 cm.

Shorten the elements as required with tin snips. Please do not use grinders, iron- or jigsaws as they will damage the surface and affect the longevity of the product. End units are easily identifiable thanks to the open top fold. Place them over the standard edging or use them as part of a straight implementation as needed.

Attention: end units are not pliable and hence cannot be bent.