



Assembly Instructions Lawn & Bed Edging wide



Wear gloves at all times!

Combine the edging at an angle of approx. 90 degrees until the click-fix elements engage in the slot. Press lightly with your thumb on the top to easily unfold the edging like the pages in a book. Whether the top edge opens into or out of the bed is up to you.

Prick the soil with a spade to install the edging. For a V-shaped indentation, rock the spade back and forth in the soil. To achieve straight lines, use a wooden board or similar as a guide.

Connect two to three elements into a unit and place them into the groove at an angle, with one end poking out completely. Join the next element here at a 90-degree angle, unfold and continue place into the groove. Protect the top with a piece of wood and carefully tap the edging to the desired height - we recommend approx. 2 - 3 cm.

Shorten the elements as required with tin snips. Please do not use grinders, iron- or jigsaws as they will damage the surface and affect the longevity of the product.

90-degree corners are achieved by joining two elements. To close any gaps, you can place elements on top of each other. To prevent gaps from opening up, fix the elements with a rivet or screw.