



# Assembly Instructions Lawn Edging “Comfort”



Wear gloves at all times!

Push the ends into each other butt to butt and screw two to three elements together to form a unit. The better you prepare the soil, the easier it will be to implement the edging. Rock the spade back and forth to create V-shaped indentations. To ensure straight lines, use a plank of wood to guide you. If you prefer wavy edges, use a garden hose to map out perfect curves. Place one of the bolted units in the groove at an angle with one end sticking out, so the next element can be joined.

Shorten the lawn edge as needed with tin snips. Please do not use iron saws, jigsaws or grinders as they will damage the surface and affect the longevity of the product. Protect the top with a piece of wood and carefully tap the edging to your desired height - we recommend to leave a height of approx. 2 - 3 cm.

**Happy and successful gardening!**